



**TECHNICAL SERVICE PART LIST
 TORNADOMATIC 1000 #9763**

⚠ WARNING ⚠

- ❶ Uses Parker-O-Lube on All O-Rings.
- ❷ Uses Permabond LM 113 or Loctite 222 on All Screws.

Tornadomatic 1000				
Number	Stock ID	Description	Quantity	Price Unit.
1	10019	Shutoff body 1 3/8"	1	
2	B2-15	Ball valve in aluminium	1	
3	2405	Trunnion nut in stainless	2	
4	R12	O-ring R12	2	
5	R7	O-ring R7	2	
6	20.5x12.5x2	White nylon spacer	2	
7	12790	Trunnion screw	2	
8	62x38x4	Flat washer 62x38x4	1	
9	64x4	O-ring 64x4	1	
10	11625	Adapter 1.5 NST	1	
11	11094	body double handle swivel	1	
12	62x48x4	Gasket 62x48x4	1	
13	11093	Inlet trunk for 1000 nozzle	1	
14	64x4	O-ring 64x4	1	
15	2403PL	Ball valve seat DN35 plastic	1	
16	STHCPM8x12	Socket hex cone set screw M8x12	4	
17	10781	Shaft pistol grip	2	
18	9235	Black silicone pistol grip	2	
19	STHCPM6x12	Socket hex cone set screw M6x12	2	
20	HUD5	Hex nut M5	2	
21	CBM5x20	Cylindric slotted head screw	2	
22	11111	Strainer, 1 3/8"	1	
23	BBØ6.35	Ball bearing Ø6.35	1	
24	7693	Swivel coupling 2.5" F NST	1	
25	3743	Gasket for 2.5" NST	1	
26	STHCFM8x10	Socket hex flat set screw M8x10	1	
27		Head assembly	1	
28	163	Spinning teeth	1	
29	154	Ring for spinning teeth	1	
30	TCHCM3x12	Socket hex round cap screw	4	
31	STHCPM5x5	Socket hex cone set screw	4	